
INSTRUCTION SHEET for 4163075 Drain Valve Kit



AWARNING

Electrical Shock Hazard Disconnect power before servicing. Replace all panels before operating. Failure to do so can result in death or electrical shock.



The special adapter mounting bracket included in the kit must be used to properly locate the drain valve on the dishwasher cross channel.

Attach the adapter mounting bracket to the back of the drain valve using the two screws in the kit as shown in location A.


Mount the drain valve to the dishwasher cross channel using the existing screws in location B.

INSTRUCTION SHEET for 4163075 Drain Valve Kit



AWARNING

Electrical Shock Hazard
Disconnect power before servicing.
Replace all panels before operating.
Failure to do so can result in death
or electrical shock.



The special adapter mounting bracket included in the kit must be used to properly locate the drain valve on the dishwasher cross channel.

Attach the adapter mounting bracket to the back of the drain valve using the two screws in the kit as shown in location A.

Mount the drain valve to the dishwasher cross channel using the existing screws in location B.