

IMPORTANT

This kit contains (2) door strikes and various door catches. Some dryers may use more than (1) catch. Note numbers stamped on the catches and/or color of the spring steel, 20 (yellow), 22 (blue) or 25 (green). Match the number and/or color, of the catch being replaced with the catch supplied in the kit. If the catch you're replacing has an 18 stamped on it or is silver in color, use the catch stamped with 20 (yellow) for replacement. The (2) door strikes contained in the kit are the same. Please replace the door strike(s) with the appropriate number of door catches being used for this repair.

If you cannot match the number on the catches, match the catch(es) by the following:

1. If your dryer has one catch and is not a 27" Wide Laundry Center or Commercial Stacked Pair, use the catch stamped with 20 (yellow) for replacement. If it is a 27" Laundry Center or Commercial Stacked Pair, use the catch stamped with 25 (green) for replacement.
2. If your dryer has 2 catches, use the catch stamped with 22 (blue) on the top and the catch stamped 20 (yellow) on the bottom.