

### Attention Installer:

1. Cut the 1/4 inch copper house supply line at the old connector and install the nut and ferrule supplied in the kit.
2. Remove the old 1/4 water line going from the water valve to the door and replace with the 5/16 water line supplied in the kit.
3. Remove the 1/4 to 1/4 connector at the bottom of the freezer door and replace with the 1/4 to 5/16 line supplied in the kit.
4. Install the new valve and connect the new 5/16 water line to the connection under the yellow coil, connect the ice maker water line to the connector under the Green coil on the new water valve.
5. Use the new water line connector to connect the new 5/16 water line from the valve to the 1/4 inch water line coming out of the bottom of the freezer door.
6. Connect the house water supply line to the new water valve using the Nut and ferrule installed on the line in step one.

PN 5304475968