

# Instruction Sheet

911851  
600VG-1295

This instruction sheet is to be used with :

**REPAIR PART NO. : 901011**


**DESCRIPTION : BI-METAL RELEASE ASSEMBLY**

The two screws provided should be used to install the replacement bi-metal release. Discard the existing screws as they may be too long and result in damage to the detergent cup if used.


To insure optimum performance of the detergent cup assembly, we also recommend the replacement of the enclosed torsion spring and cam. Discard the existing cam, compression spring and return spring.

## To Install Cam and Spring:

1. Place torsion spring over shaft for detergent cup cover, with end of spring positioned in detergent cup as shown.



2. Place cam over spring and shaft for detergent cup cover, making sure end of spring is aligned into window of "V" stop on cam.



3. Push cam in to compress spring and turn cam counterclockwise 180 degrees.
4. Hold cam in place, insert retaining pin through shaft for cover.



5. Release pressure on cam.

Mechanical operation of the assembly can be checked by closing the cover over the right-hand side of the detergent cup and manually tripping the bi-metal assembly.